NITROX LP CONNECTION TO HP COMPRESSOR

IT IS VERY SIMPLE TO CONNECT A LOW PRESSURE COMPRESSOR SUPPLYING NITROX MIX TO A HIGH PRESSURE COMPRESSOR BY AEROTECNICA COLTRI.



CONNECT THE OUTLET TUBE OF NITROX
MIX FROM THE LP COMPRESSOR
TO THE HP COMPRESSOR



INSERT THE CONNECTION TUBE
TO THE SUCTION FILTER
OF THE HIGH PRESSURE COMPRESSOR



START THE LP COMPRESSOR





SET O₂ PERCENTAGE WITH YELLOW ANALYZER



START TEH HP COMPRESSOR



CHECK O₂ PERCENTAGE
WITH PRO O₂ ANALYZER LOCATED ON
THE HIGH PRESSURE COMPRESSOR